

HOW TO MAKE A DUCT TAPE WALLET

1. Lay a 7-8" strip of duct tape sticky side up on your work surface and place a second strip sticky side up so it slightly overlaps the edge of the first strip. Repeat until you have four strips of duct tape overlapping.
2. Turn the sheet so the sticky-side-up strips run vertically and lay a strip sticky side down over the sheet horizontally. Repeat with additional strips of overlapping duct tape until the sticky sides are covered.
3. Trim off edges.
4. Fold the sheet in half on the long edge so you have a rectangle.
5. Use a piece of tape to seal the edge on one of the short sides of the rectangle. Trim off the extra tape.
6. Fold the wallet in half so the short sides line up. *Note: Do this before taping the other side so that the wallet will fold without bulges.*
7. Keeping the wallet in the folded position, trim any excess, and tape the other side.
8. **Optional: Personalize the wallet with initials, favorite colors, or a personal trademark.**